

Usage Manual



STEP/MONOSTABLE&CALL RESET RELAY

No.288th. Wei 17 Road, Economic Development
Zone, Yueqing City Zhejiang China.
Tel: 0086-577-62718777 Fax: 0086-577-62774090
Email: sales@etek-china.com

Thank you for choosing EK Series Reset relay. Please read this manual before installation, operation and maintenance.


STANDARD AND QUALITY CERTIFICATES



Contact Configuration
Universal Power Supply
2 LED Status Indicators
SPDT or DPDT

Rated Current 5A or 16A
Only 17.5 mm Wide
DIN Rail Mountable
CE RoHS Compliant

Technical Data


Type	Spec	Description		Functions
EKR8-2010	SPDT 5A / 16A AC240V	CALL / RESET RELAY		 CALL/RESET
EKR8-2020	DPDT 5A / 16A AC240V			
EKR8-2110	SPDT 5A / 16A AC240V	STEP/MONOSTABLE RELAY		 Step Monostable STEP/MONOSTABLE
EKR8-2210	SPDT 5A / 16A AC240V	STEP	STEP RELAY	
EKR8-2220	DPDT 5A / 16A AC240V	STEP 0		

Type	Spec	Description		Functions
EKR8-2221	DPDT 5A / 16A AC240V	STEP 1	STEP RELAY	 STEP
EKR8-2222		STEP 2		
EKR8-2223		STEP 3		


			
STEP0	STEP 1	STEP2	STEP3

☐: **Operating voltage:**
220: AC220V D24: DC24V A24: AC24V H00: AC/DC12-240V
More...


MODEL & EXPLANATION



EKR8-2010
EKR8-2020




EKR8-2110



EKR8-2210
EKR8-2220
EKR8-2221
EKR8-2222
EKR8-2223

- ① Power Indicator
- ② Work Indicator

DIMENSIONS INCHES(MILLIMETERS)



WIRING DIAGRAMS

